



NOTE:

1. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A HARD BOARD IS REQUIRED ON MECHANICAL SYSTEMS ONLY.
2. FLASHINGS MAY BE ADHERED OR INSTALLED DRY. SEE SPEC FOR DIMENSIONS.
3. KEEP FASTENERS BACK FROM CORNER 6" (152 mm) MAX. IN BOTH HORIZONTAL AND VERTICAL APPLICATIONS
4. 25 YEAR GUARANTEES AND ABOVE MUST USE EXTREME ACCESSORIES
5. IF EVERGUARD® FREEDOM™ MEMBRANE IS USED, BONDING ADHESIVE IS NOT NEEDED AND WALL MUST BE PRIMED.
6. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO EVERGUARD® DETAIL 115).



www.gaf.com
1 Campus Drive,
Parsippany, NJ 07054



DRAWING #
327B

SCALE
N.T.S.

**INSIDE CORNER REINFORCEMENT -
PREFORMED CORNER DETAIL**

THIS DETAIL APPLIES TO TPO AND PVC MEMBRANES

THIS DETAIL APPLIES TO:

ALL SYSTEMS

REVISION DATE
6-20-16