

- 2. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A HARD BOARD IS REQUIRED ON MECHANICAL SYSTEMS ONLY.
- 3. APPLY HEAT TO DETAIL MEMBRANE AND FORM BY HAND PRIOR TO INSTALLING.
- 4. APPLY EVERGUARD 0 TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO EVERGUARD 0 DETAIL 115).

CAF ®	EverGuard ROOF PENETRATION SERIES	508	HIGH TEMPERATURE STACK FLASHING DETAIL	THIS DETAIL APPLIES TO: ALL SYSTEMS
www.gaf.com 1 Campus Drive. Parsippany, NJ 07054	GENIEG	SCALE N.T.S.		REVISION DATE 5-25-16