



NOTE:

1. ADD BALLAST PER SPEC FOR BALLASTED SYSTEMS.
2. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO EVERGUARD DETAIL 115).



EverGuard
SINGLE-PLY ROOFING SYSTEMS
PARAPET WALL &
CURB SERIES

DRAWING #

319

COUNTERFLASHING RE-ROOF DETAIL

SCALE
N.T.S.

THIS DETAIL APPLIES TO:
Adhered Systems
Ballast Applied Systems
Mechanically Attached Systems

REVISION DATE
6-26-17

1361 Alps Rd.
Wayne, NJ 07470
www.gaf.com