

- 1. BE SURE TO CLEAN METAL AND MEMBRANE WITH EVERGUARD® TPO SEAM CLEANER BEFORE PRIMING.
- 2. APPLY FLEXSEAL™ CAULK GRADE SEALANT TO ALL EVERGUARD® STRIP-IN TAPE EDGES.
- 3. MEMBRANE MUST BE PRIMED AND DRY PRIOR TO APPLYING EVERGUARD® DOUBLE SIDED TAPE.
- 4. HANGERS MUST TERMINATE INTO FASCIA, NOT INTO ROOF SURFACE

www.gaf.com 1 Campus Drive. Parsippany, NJ 07054	ROOF EDGE SERIES	711	GUTTER EDGE DETAIL	THIS DETAIL APPLIES TO: RapidSeam Systems
		SCALE N.T.S.	TPO ONLY	REVISION DATE 5-26-16