



**NOTE:**

1. SET PRIMED FLANGE IN ROOF CEMENT ON MOP MB, COLD MB, SA MB, AND BUR.
2. SET PRIMED FLANGE IN HEAT-SOFTENED MEMBRANE ON TORCH APP OR HEAT-WELD SBS SYSTEMS.



**GAFGLAS®**  
Built-Up Roofing Systems  
**RUBEROID®**  
Modified Bitumen Roofing Systems

www.gaf.com  
1 Campus Drive,  
Parsippany, NJ  
07054

**ALTERNATE ROOF PENETRATION  
FLASHING DETAIL**

DRAWING #

**29**

SCALE

N.T.S.

SYSTEM

**MB/BUR**

ISSUE/ REVISION DATE

7-01-14