



NOTE:

1. INSTALL CONTINUOUS ANCHOR CLEAT OVER THE TURNED-DOWN CAP SHEET, NAILING PER INSTRUCTIONS.
2. SET PREFABRICATED CORNER SECTIONS.
3. INSTALL FASCIA LENGTHS WITH CONCEALED JOINT-SPLICE PLATES AT ALL JOINTS.
4. PRIME PERFORATED TOP PLATE, THEN CAREFULLY SEAL THE FLASHING PLY TO THE CAP SHEET.



WWW.GAF.COM
1 Campus Drive.
Parsippany, NJ
07054

GAFGLAS®
Built-Up Roofing Systems
RUBEROID®
Modified Bitumen Roofing Systems

GRAVEL GUARD MB FLASHING DETAIL

DRAWING #

22

SYSTEM

MB/BUR

SCALE

N.T.S.

ISSUE/ REVISION DATE

7-01-14