



NOTE:

1. REMEMBER TO INSTALL EVERGUARD® UNREINFORCED OR PREMANUFACTURED OUTSIDE CORNERS TO THE SCUPPERS' FOUR ROOF SIDE CORNERS.
2. OPTIONS 1 & 2 EITHER PRE-FAB OR FIELD FAB.
3. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO DETAIL FD 115).



PARAPET WALL & CURB SERIES

COATED METAL WALL SCUPPER

HEATWELD ONLY

DRAWING #

311

SCALE

N.T.S.

SYSTEM

FD

ISSUE/ REVISION DATE

3-1-10