



NOTE:

1. TO MAKE A SEAM ON RAPID SEAM™ WITHOUT RAPID SEAM™ PRESENT, YOU MUST USE GAF CLEANER AS WELL AS GAF PRIMER TO PREP THE AREA.
2. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO DETAIL FD 115).



EverGuard® Freedom™
Self-Cleaning Roofing System

ROOF PENETRATION SERIES

TERMINATION AT R.T.U. WITH WELDED LAP

HEATWELD & RAPIDSEAM

DRAWING #
503A

SCALE
N.T.S.

SYSTEM
FD

ISSUE/ REVISION DATE
3-1-10