



NOTE:

1. TO MAKE A SEAM ON RAPID SEAM™ WITHOUT RAPID SEAM™ PRESENT, YOU MUST USE GAF CLEANER AS WELL AS GAF PRIMER TO PREP THE AREA.
2. DRAIN PIPE SHALL BE CLEANED SO THAT EXPANDING TAPE SEAL CAN SEAT COMPLETELY AGAINST DRAIN PIPE AFTER RELEASE PAPER HAS BEEN REMOVED.
3. EVERGUARD TPO DRAIN CAN ALSO BE USED AS A RETROFIT DRAIN.
4. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO DETAIL FD 115) AND ALL RAPIDSEAM™ SEAMS.



EverGuard® Freedom™
Self-Adhering Roofing System

ROOF PENETRATION SERIES

DRAIN - PREFABRICATED TPO DRAIN WITH FLANGE

HEATWELD & RAPIDSEAM

DRAWING #

521

SCALE

N.T.S.

SYSTEM

FD

ISSUE/ REVISION DATE

3-1-10