



**NOTE:**

1. TO MAKE A SEAM ON RAPID SEAM™ WITHOUT RAPID SEAM™ PRESENT, YOU MUST USE GAF CLEANER AS WELL AS GAF PRIMER TO PREP THE AREA.
2. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO DETAIL FD 115).



EverGuard®  
**Freedom™**  
Self-Adhering Roofing System

ROOF PENETRATION SERIES

**ROOF HATCH DETAIL**

HEATWELD & RAPIDSEAM

DRAWING #

505

SCALE

N.T.S.

SYSTEM

FD

ISSUE/ REVISION DATE

3-1-10