



NOTES:

1. NEW CRICKETS SHALL BE "SEALED" BY PLACING A BEAD OF TOPCOAT FLEXSEAL UNDER THE FLANGES BEFORE THEY ARE MECHANICALLY ATTACHED
2. VERTICAL SEAMS TO BE CUT BACK A MINIMUM OF 2" FROM CRICKET



TOPCOAT®
COATINGS, SEALANTS AND ADHESIVES

HVAC CURB DETAIL

DRAWING #

506

SYSTEM

TC

WWW.GAF.COM
1361 Alps Rd.
Wayne, NJ 07470

ROOF
PENETRATION
SERIES

SCALE

N.T.S.

ISSUE/ REVISION DATE

12-01-12