



NOTES:

1. NEW CRICKETS SHALL BE "SEALED" BY PLACING A BEAD OF TOPCOAT FLEXSEAL UNDER THE FLANGES BEFORE THEY ARE MECHANICALLY ATTACHED
2. VERTICAL SEAMS TO BE CUT BACK A MINIMUM OF 2" FROM CRICKET



TOPCOAT®
COATINGS, SEALANTS AND ADHESIVES

SCUTTLE HATCH FLASHING DETAIL

DRAWING #

510

SYSTEM

TC

WWW.GAF.COM
1361 Alps Rd.
Wayne, NJ 07470

**ROOF
PENETRATION
SERIES**

SCALE

N.T.S.

ISSUE/ REVISION DATE

12-01-12