



**NOTES:**

1. NEW CRICKETS SHALL BE "SEALED" BY PLACING A BEAD OF TOPCOAT FLEXSEAL UNDER THE FLANGES BEFORE THEY ARE MECHANICALLY ATTACHED
2. VERTICAL SEAMS TO BE CUT BACK A MINIMUM OF 2" FROM CRICKET



**TOPCOAT®**  
COATINGS, SEALANTS AND ADHESIVES

**SKYLIGHT CURB DETAIL**

DRAWING #

**505**

SYSTEM

**TC**

WWW.GAF.COM  
1361 Alps Rd.  
Wayne, NJ 07470

**ROOF  
PENETRATION  
SERIES**

SCALE

**N.T.S.**

ISSUE/ REVISION DATE

**12-01-12**