



**NOTE:**

1. MBOOT IS INSTALLED ON THE BASE/PLY SHEET(S) PRIOR TO INSTALLATION OF MEMBRANE.
2. INSTALL METAL CLAMP AND CAULK SEALANT AT TOP OF BOOT.



**GAFGLAS®**  
Built-Up Roofing Systems  
**RUBEROID®**  
Modified Bitumen Roofing Systems

**ADJUSTABLE MVENT FLASHING DETAIL**

DRAWING #

**26**

SYSTEM

**MB/BUR**

SCALE

N.T.S.

ISSUE/ REVISION DATE

10-01-10