



NOTES:

1. NEW CRICKETS SHALL BE "SEALED" BY PLACING A BEAD OF TOPCOAT FLEXSEAL UNDER THE FLANGES BEFORE THEY ARE MECHANICALLY ATTACHED
2. VERTICAL SEAMS TO BE CUT BACK A MINIMUM OF 2" FROM CRICKET



ROOF
PENETRATION
SERIES

SCUTTLE HATCH FLASHING DETAIL

DRAWING #

510

SCALE

N.T.S.

SYSTEM

TC

ISSUE/ REVISION DATE

6-01-11