



**NOTE:**

1. BASE/PLY SHEET(S) TURNED OVER EDGE A MINIMUM OF 1 1/2" (38mm) OR THICKNESS OF NAILER WHICHEVER IS GREATER OR A SEPARATION MEMBRANE SHEET IS INSTALLED AS SHOWN
2. PRIME BOTH SIDES OF FLANGE AND SET IT IN ROOF CEMENT ON MOP MB, COLD MB SA, MB AND BUR. SET PRIMED FLANGE IN HEAT SOFTENED MEMBRANE ON TORCH APP AND HEAT-WELD SBS SYSTEMS.



**TAPERED EDGE FLASHING DETAIL**

DRAWING #  
**02**

SYSTEM  
**MB/BUR**

SCALE  
N.T.S.

ISSUE/REVISION DATE  
10-01-10