



**NOTE:**

1. MASONRY WALLS TO BE PRIMED PRIOR TO FLASHING. WOOD WALLS REQUIRE BASE SHEET NAILED TO WALL 8" O.C. ALONG TOP AND LAPS AND 8" O.C. THROUGHOUT THE FIELD OF THE BASE SHEET ON THE WALL.
2. REFER TO DETAIL MB / BUR 7 FOR ALTERNATE WALL FLASHING METHOD.
3. FASTEN BASE FLASHING APPROXIMATELY 8" O.C. FOR HEIGHTS UP TO 12" AND 4" O.C. FOR HEIGHTS UP TO 24".
4. FOR WALL FLASHINGS IN EXCESS OF 4' CONTACT GAF TECHNICAL SERVICES AT 1-800-ROOF-411.
5. BASE FLASHING ON ALL 15 AND 20 YEAR GUARANTEE SYSTEMS MUST HAVE A BASE PLY. REFER TO FLASHING MEMBRANE APPLICATION AND FLASHING SPECIFICATION PLATES.



**GAFGLAS®**  
Built-Up Roofing Systems  
**RUBEROID®**  
Modified Bitumen Roofing Systems

## HIGH PARAPET WALL DETAIL

DRAWING #

06

SYSTEM

MB/BUR

SCALE

N.T.S.

ISSUE/ REVISION DATE

11-01-10