



NOTE:

1. INSTALL CONTINUOUS ANCHOR CLEAT OVER THE TURNED DOWN CAP SHEET, NAILING PER INSTRUCTIONS.
2. SET PREFABRICATED CORNER SECTIONS.
3. INSTALL FASCIA LENGTHS WITH CONCEALED JOINT-SPLICE PLATES AT ALL JOINTS.
4. PRIME PERFORATED TOP PLATE THEN CAREFULLY SEAL THE FLASHING PLY TO THE CAP SHEET.



GAFGLAS
Built-Up Roofing Systems
RUBEROID
Modified Bitumen Roofing System

GRAVEL GUARD MB FLASHING DETAIL

DRAWING #
22

SYSTEM
MB/BUR

SCALE
N.T.S.

ISSUE/ REVISION DATE
10-01-10