



NOTE:

1. SET PRIMED FLANGE IN ROOF CEMENT ON MOP MB, COLD MB, SA MB AND BUR.
2. SET PRIMED FLANGE IN HEAT SOFTENED MEMBRANE ON TORCH APP OR HW SBS SYSTEMS.



GAFGLAS
Built-Up Roofing Systems
RUBEROID
A Modified Bitumen Roofing System

**ALTERNATE ROOF PENETRATION
FLASHING DETAIL**

DRAWING #

29

SYSTEM

MB/BUR

SCALE

N.T.S.

ISSUE/ REVISION DATE

10-01-10