



NOTE:

1. FOR HEAT WELDING LAPS USE 1 1/2" WELD WITH MACHINE AUTOMATIC MACHINE WELDER.
2. APPLY EVERGUARD[®] TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES (REFER TO DETAIL MA/FA/BA 115).

 www.gaf.com 1361 Alps Rd. Wayne, NJ 07470	 SINGLE-PLY ROOFING SYSTEMS	SIDE LAP DETAIL	DRAWING # 102	SYSTEM FA/BA
		FIELD OF ROOF SERIES	SCALE N.T.S.	ISSUE/ REVISION DATE 7-01-11