



NOTE:

1. FIELD FABRICATED EXPANSION JOINT SHOULD NOT BE FLEECE-BACK OR SELF ADHERING MEMBRANE. USE STANDARD EVERGUARD MEMBRANE
2. APPLY EVERGUARD® TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES (REFER TO DETAIL MA/FA/BA 115).



EverGuard
SINGLE-PLY ROOFING SYSTEMS

EXPANSION JOINT
SERIES

**FIELD FABRICATED EXPANSION JOINT
DETAIL -FLAT TYPE**

DRAWING #	SYSTEM
401B	MA/FA/BA
SCALE	ISSUE/ REVISION DATE
N.T.S.	9-01-09