



NOTE:

1. TO BE USED WHEN TEMPERATURE OF STACK EXCEEDS 160° F.
2. FOR INSULATION THICKNESSES GREATER THAN 6", CONTACT GAFMC CONTRACTOR SERVICES FOR ALTERNATE MEMBRANE ATTACHMENT REQUIREMENTS.
3. APPLY HEAT TO UNREINFORCED FLASHING AND FORM BY HAND PRIOR TO HOT AIR WELDING.
4. APPLY EVERGUARD® TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES (REFER TO DETAIL MA/FA/BA 115).



EverGuard
SINGLE-PLY ROOFING SYSTEMS

ROOF PENETRATION SERIES

HIGH TEMPERATURE STACK FLASHING

DRAWING #

508

SYSTEM

MA/FA/BA

SCALE

N.T.S.

ISSUE/REVISION DATE

9-01-09