



NOTE:

1. ATTACH BRACKETED SYSTEM PER MANUFACTURING INSTRUCTIONS
2. EVERGUARD WALKWAY PADS CAN BE CUT INTO STRIPS OR INDIVIDUAL PADS FOR EACH BRACKET BASE. FOR HEAT WELDING LAPS USE 1-1/2" WELD WITH AUTOMATIC MACHINE WELDER AND 2" WELD WITH HAND WELDER.
3. APPLY EVERGUARD[®] TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES (REFER TO DETAIL MA/FA/BA 115).
4. WOOD BLOCKING REQUIRED ON NEW CONSTRUCTION. FOR EXISTING ROOF, FASTENERS MUST PENETRATE INTO DECK SUBTRATE



PV SOLAR SERIES

ROOF SECUREMENT - PAD OPTION

BRACKETED SYSTEM - NON-ATTACHED BALLASTED SYSTEMS

DRAWING #

101B

SCALE

N.T.S.

SYSTEM

PV

ISSUE/ REVISION DATE

2-1-11