



NOTE:

1. FA AND BA SYSTEMS DO NOT REQUIRE FASTENERS AT RIDGE AREA.
2. THE FOLLOWING APPLIES FOR MA SYSTEMS ONLY: FOR INSULATION THICKNESSES GREATER THAN 8", CONTACT GAF CONTRACTOR SERVICES FOR ALTERNATE ATTACHMENT REQUIREMENTS. THESE METHODS MAY INCLUDE THE USE OF A HARD BOARD COVERING THE ASSEMBLY.
3. DO NOT RUN CAP SHEET INTO THE PERIMETER HALF SHEET REGION IN MA SYSTEMS.
4. APPLY EVERGUARD® TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES (REFER TO DETAIL MA/FA/BA 115).

 <small>WWW.GAF.COM</small> 1361 Alps Rd. Wayne, NJ 07470	 SINGLE-PLY ROOFING SYSTEMS	<h2>RIDGE DETAIL</h2>	DRAWING #	SYSTEM
			110	MA
FIELD OF ROOF SERIES			SCALE	ISSUE/ REVISION DATE
			N.T.S.	7-01-11