



**NOTE:**

1. ADD BALLAST PER SPEC FOR BA SYSTEMS.
2. APPLY EVERGUARD® TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES ( REFER TO DETAIL MA/FA/BA 115).

**SNAP-ON FASCIA ROOF  
EDGE DETAIL - OPTION 2**

DRAWING #

206

SYSTEM

MA/FA/BA

SCALE

N.T.S.

ISSUE/ REVISION DATE

7-01-11



WWW.GAF.COM  
1361 Alps Rd.  
Wayne, NJ 07470

ROOF EDGE SERIES