



**NOTE:**

1. SCREWS/ ANCHORS 6" O.C. REQ'D FOR BA SYSTEMS. (IF BA SYSTEM USED IN A HIGH PRESSURE SITUATION ATTACH BAR 6" O.C.).
2. PLATES & FASTENERS MAY BE USED IN LIEU OF TERM BAR IN NON-PRESSURIZED SITUATIONS.
3. THIS DETAIL NEEDS TO BE USED FOR PRESSURIZED SITUATIONS.
4. APPLY EVERGUARD® TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES (REFER TO DETAIL MA/FA/BA 115 ).



PARAPET WALL & CURB SERIES

## ALTERNATE WALL BASE TERMINATION DETAIL

DRAWING #

307

SCALE

N.T.S.

SYSTEM

MA/FA/BA

ISSUE/ REVISION DATE

6-01-10