



**NOTE:**

1. FOUR CORNER CURB WRAP PIECES ARE NEEDED TO COMPLPETE. VARYING SIZES MAY BE NEEDED TO COMPLETE
2. INSTALLATION OF FASTENERS & PLATES 12" O.C. APPROXIMATELY 6" (150 mm) FROM CORNER.
3. FLASHINGS MAY BE ADHERED OR INSTALLED DRY. SEE SPEC FOR DIMENSIONS.
4. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO DETAIL MA/FA/BA 115).



PARAPET WALL & CURB SERIES

**CORNER CURB WRAP DETAIL**

TPO ONLY

DRAWING #

325

SCALE

N.T.S.

SYSTEM

MA/FA/BA

ISSUE/ REVISION DATE

9-01-09