



NOTE:

1. ALL FLASHINGS ON EXPANSION JOINTS MUST BE ADHERED.
2. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO DETAIL MA/FA/BA 115).

 GAF <small>GAF MATERIALS CORPORATION www.gaf.com</small>	 EverGuard <small>SINGLE-PLY ROOFING SYSTEM</small>	FACTORY FABRICATED EXPANSION JOINT DETAIL - CURB TYPE	DRAWING #	SYSTEM
			402A	MA/FA/BA
EXPANSION JOINT SERIES		TPO ONLY	SCALE	ISSUE/ REVISION DATE
			N.T.S.	12-01-09