



NOTE:

1. ALL FLASHINGS ON EXPANSION JOINTS MUST BE ADHERED.
2. FIELD FABRICATED EXPANSION JOINT SHOULD NOT BE FLEECE-BACK OR SELF ADHERING MEMBRANE. USE STANDARD EVERGUARD MEMBRANE
3. APPLY EVERGUARD® TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES (REFER TO DETAIL MA/FA/BA 115).



EXPANSION JOINT SERIES

FIELD FABRICATED EXPANSION JOINT DETAIL - CURB TYPE

DRAWING #

402B

SCALE

N.T.S.

SYSTEM

MA/FA/BA

ISSUE/ REVISION DATE

9-01-09