



NOTE:

1. DO NOT CUT PREMOLDED BOOT. IT MUST BE PULLED OVER VENT PIPE.
2. TPO SELF-ADHERED PIPE BOOTS AND PRIMER MAY BE USED WITH TPO SYSTEMS FOR UP TO A 15 YEAR GUARANTEE.
3. IF THE PLATES AND FASTENERS INTRUDE INTO BOOT FLANGE AREA, THEN A TARGET MUST FIRST BE INSTALLED OVER PLATES AND FASTENERS BEFORE BOOT INSTALLATION.
4. APPLY EVERGUARD® TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES (REFER TO DETAIL MA/FA/BA 115).
5. ATTACH BRACKETED SYSTEM PER MANUFACTURING INSTRUCTIONS



PV SOLAR SERIES

PREMOLDED PENETRATION FLASHING

BRACKETED SYSTEM - ATTACHED BALLASTED SYSTEMS

DRAWING #

506

SCALE

N.T.S.

SYSTEM

PV

ISSUE/ REVISION DATE

2-1-11