



1. APPLY EVERGUARD® TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES (REFER TO DETAIL MA/FA/BA 115).
2. ATTACH BRACKETED SYSTEM PER MANUFACTURING INSTRUCTIONS

 GAF MATERIALS CORPORATION www.gaf.com	 SINGLE-PLY ROOFING SYSTEMS	FIELD-WRAPPED PENETRATION FLASHING	DRAWING #	SYSTEM
		PV SOLAR SERIES	BRACKETED SYSTEM - ATTACHED BALLASTED SYSTEMS	507
			SCALE	ISSUE/ REVISION DATE
			N.T.S.	2-1-11