



NOTE:

1. A FIELD WELD CANNOT PASS WITHIN 9" OF THE CLAMPING, OR WITHIN THE DRAIN SUMP ITSELF.
2. MEMBRANE MUST EXTEND MINIMUM 1" BEYOND THE BOLT HOLES, THE CLAMPING RING BOLTS MUST PENETRATE THE MEMBRANE.
3. TAPERED INSULATION TO CREATE A ROOF SUMP MINIMUM 36" X 36" IN SIZE. (IF APPLICABLE)
4. EVERGUARD[®] ADHESIVE/ASPHALT (NOT SHOWN) REQ'D FOR FA SYSTEMS.
5. USE ONE FULL TUBE OF GAF WATER BLOCK PER DRAIN.
6. STONE/PAVER BALLAST (NOT SHOWN) REQUIRED FOR BA SYSTEMS.



ROOF PENETRATION SERIES

DRAIN -STANDARD ROOF DRAIN FLASHING

DRAWING #

513

SCALE

N.T.S.

SYSTEM

MA/FA/BA

ISSUE/ REVISION DATE

9-01-09