



NOTE:

1. ATTACH BRACKETED SYSTEM PER MANUFACTURING INSTRUCTIONS
2. IF THE PLATES AND FASTENERS INTRUDE INTO BOOT FLANGE AREA, THEN A TARGET MUST FIRST BE INSTALLED OVER PLATES AND FASTENERS BEFORE BOOT INSTALLATION.
3. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO DETAIL MA/FA/BA 115).



PV SOLAR SERIES

SPLIT PIPE BOOT

BRACKETED SYSTEM - ATTACHED BALLASTED SYSTEMS

DRAWING #

524

SCALE

N.T.S.

SYSTEM

PV

ISSUE/ REVISION DATE

2-1-11