



NOTE:

1. METAL COUNTERFLASHING IS NOT REQ. IF MEMBRANE IS RUN UP AND OVER CURB WALLS PRIOR TO INSTALLATION OF R.T.U.
2. INSTALL METAL WORK IN ACCORDANCE WITH CURRENT SMACNA RECOMMENDATIONS.
3. TO MAKE A SEAM ON RAPID SEAM™ WITHOUT RAPID SEAM™ PRESENT, YOU MUST USE GAF CLEANER AS WELL AS GAF PRIMER TO PREP THE AREA.
4. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO DETAIL FD 115).



EverGuard
Freedom
Self-Adhering Roofing System

ROOF PENETRATION
SERIES

TERMINATION AT R.T.U. WITH
COUNTERFLASHING

HEATWELD & RAPIDSEAM

DRAWING #
503B

SCALE
N.T.S.

SYSTEM
FD

ISSUE/ REVISION DATE
3-1-10