

- 1. CLEAN METAL AND MEMBRANE WITH EVERGUARD®TPO SEAM CLEANER AND ALLOW TO DRY BEFORE PRIMING.
- 2. EVERGUARD® TPO COVER TAPE ONLY TO BE USED WITH TPO MEMBRANE SYSTEMS.
- 3. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A HARD BOARD IS REQUIRED ON MECHANICALLY FASTENED SYSTEMS ONLY.
- 4. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO EVERGUARD® DETAIL 115).

	CAF	EverGuard ROOF EDGE SERIES	214	COVER TAPE AT GUTTER EDGE DETAIL	THIS DETAIL APPLIES TO: Adhered Systems Mechanically Attached Systems Self - Adhered Systems
	www.gaf.com 1 Campus Drive. Parsippany, NJ 07054		SCALE N.T.S.		REVISION DATE 6-20-16