



Note: For all applications, the butt joints of the Weather Blocker™ Starter Shingles must be offset from the butt joints of the first course of shingles by 4" or more. For long eaves, a 10" (254 mm) piece of Weather Blocker™ Starter may need to be installed periodically to adjust the offset. The frequency of this adjustment will depend on the length of the shingles being installed.



www.gaf.com  
1361 Alps Rd.  
Wayne, NJ 07470

BRAND SERIES

Weather Blocker™  
Starter Strip  
Shingles

REVISION DATE

6-01-12

SCALE

N.T.S

## WEATHERBLOCKER™ STARTER STRIP SHINGLE INSTALLATION DETAIL (OF AT LEAST 6" EXPOSURE)

DETAIL NUMBER

# 02

DETAIL REFERENCE

## SS-WB2