



**NOTE:**

1. R.T.A STRIP MAY BE FIELD-FABRICATED OUT OF EVERGUARD® FREEDOM™ TPO MEMBRANE. REMOVE FILM BEFORE INSTALLING BASE SHEET.
2. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A HARD BOARD IS REQUIRED ON MECHANICAL SYSTEMS ONLY.
3. IF EVERGUARD® FREEDOM™ MEMBRANE IS USED, BONDING ADHESIVE IS NOT NEEDED AND WALL MUST BE PRIMED.
4. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO EVERGUARD® DETAIL 115).



**EverGuard**  
SINGLE-PLY ROOFING SYSTEMS  
PARAPET WALL &  
CURB SERIES

DRAWING #  
**326C**

**R.T.A. STRIP - BASE TIE-IN DETAIL**

THIS DETAIL APPLIES TO:  
Adhered Systems  
Self-Adhered Systems  
Ballasted Systems

www.gaf.com  
1 Campus Drive,  
Parsippany, NJ 07054

SCALE  
N.T.S.

TPO ONLY

REVISION DATE  
6-20-16