



NOTE:

1. R.T.A STRIP MAY BE FIELD FABRICATED OUT OF EVERGUARD® FREEDOM™ MEMBRANE. REMOVE FILM BEFORE INSTALLING BASE SHEET.
2. THIS DETAIL IS NOT TO BE USED FOR EVERGUARD® PVC MEMBRANES OR MECHANICALLY ATTACHED SYSTEMS.
3. IF EVERGUARD® FREEDOM TPO IS USED, BONDING ADHESIVE NOT NEEDED AND WALL MUST BE PRIMED WITH TPO PRIMER.
4. IF EVERGUARD® FREEDOM™ MEMBRANE IS USED, BONDING ADHESIVE IS NOT NEEDED AND WALL MUST BE PRIMED.
5. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO EVERGUARD® DETAIL 115).



EverGuard
SINGLE-PLY ROOFING SYSTEMS
PARAPET WALL &
CURB SERIES

www.gaf.com
1 Campus Drive,
 Parsippany, NJ 07054

DRAWING #
326D

SCALE
N.T.S.

**R.T.A. STRIP - ALTERNATE BASE
TIE-IN DETAIL**

TPO ONLY

THIS DETAIL APPLIES TO:
Adhered Systems
Self-Adhered Systems
Ballasted Systems

REVISION DATE
6-20-16