



NOTE:

1. TERMINATION BAR NEEDED FOR PRESSURIZED SITUATIONS. PLATES & FASTENERS MAY BE USED IN LIEU OF TERM BAR IN NON-PRESSURIZED SITUATIONS.
2. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A HARD BOARD IS REQUIRED ON MECHANICALLY FASTENED SYSTEMS ONLY.
3. IF EVERGUARD® FREEDOM™ MEMBRANE IS USED, BONDING ADHESIVE IS NOT NEEDED AND WALL MUST BE PRIMED.
4. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO EVERGUARD® DETAIL 115).



DRAWING #
309

SCALE
N.T.S.

**WALL BASE TERMINATION -
RAPIDSEAM™ DETAIL**

THIS DETAIL APPLIES TO:
**Self-Adhered
Systems**
(RAPIDSEAM™ TECHNOLOGY
MEMBRANE ONLY)

REVISION DATE
5-1-16