



**NOTE:**

1. DO NOT CUT PREMOLDED BOOT. IT MUST BE PULLED OVER SOLAR MOUNT CYLINDRICAL STAND OFF.
2. IF THE PLATES AND FASTENERS INTRUDE INTO BOOT FLANGE AREA, THEN A TARGET MUST FIRST BE INSTALLED OVER PLATES AND FASTENERS BEFORE BOOT INSTALLATION.
3. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO EVERGUARD® DETAIL 115).



PV SOLAR SERIES

**PREMOLDED PENETRATION FLASHING DETAIL**

DRAWING #  
PV-C-03

SCALE  
N.T.S.

SYSTEM  
PV

ISSUE/ REVISION DATE  
5-3-13