



NOTE:

1. IF THE PLATES AND FASTENERS INTRUDE INTO BOOT FLANGE AREA, THEN A TARGET MUST FIRST BE INSTALLED OVER PLATES AND FASTENERS BEFORE BOOT INSTALLATION.
2. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO EVERGUARD® DETAIL 115).
3. USE EVERGUARD EXTREME® TPO ACCESSORIES FOR DIRECT ATTACHED PV SYSTEMS

| | | | | |
|---|---|---------------------------------|-----------|----------------------|
|  www.gaf.com |  SINGLE-PLY ROOFING SYSTEMS | <h2>SPLIT PIPE BOOT DETAIL</h2> | DRAWING # | SYSTEM |
| | | | PV-C-05 | PV |
| PV SOLAR SERIES | | TPO SYSTEMS ONLY | SCALE | ISSUE/ REVISION DATE |
| | | | N.T.S. | 5-3-13 |