

EverGuard® TPO **Self-Adhered Vent Boot** Single-Ply Accessory



Description:

Increase efficiency when covering pipes and conduits with factory-built EverGuard® Self-Adhered TPO Vent Boots. These single-ply roofing system preformed accessories provide roofing contractors with an effective, easy-to-install detail. GAF manufactures these and other accessories from its proven, durable EverGuard® TPO single-ply reinforced membrane. GAF TPO accessories can help you reduce installation labor, risk of leaks, and callbacks, while helping you create a uniform look.

Application:

Preformed accessories may be installed on mechanically attached, fully adhered, or self-adhered EverGuard® and EverGuard Extreme® TPO roofing systems.

Benefits:

GAF Self-Adhered TPO Accessories can be installed without welding, which means:

- Easier installation
- Lower experience level required
- Great for repairs
- Time savings

Product Information:

EverGuard® Self-Adhered TPO Vent Boots are constructed from EverGuard® reinforced membrane. One standard size accommodates 1" – 6" (25.4 mm – 152.4 mm) pipes and conduits. Vent Boots come with stainless steel clamping rings for the top of the penetration.

Installation Instructions:

1. Roof membrane must be mechanically attached at the base of each penetration with four fasteners and plates.
2. If plates and fasteners intrude into boot flange area, a TPO target must FIRST be installed over plates and fasteners
3. TPO must be cleaned with EverGuard® TPO Seam Cleaner or EverGuard® TPO Low VOC Seam Cleaner and allowed to fully flash off. Note: Aged membrane with visible contaminants may need to be cleaned first with a household cleaner.
4. Prime the TPO field membrane with EverGuard® TPO Primer and allow it to fully flash off.
5. Remove release liner on the Self-Adhered Vent Boot to expose adhesive.
6. Install EverGuard® Water-Block on the penetration where it will meet the top of the pipe boot.
7. Install the Self-Adhered Vent Boot over the vent pipe.
8. Using a silicone hand roller, adhere the flange onto the membrane. Where the Self-Adhered Vent Boot is installed over field seams, slightly heat the pipe boot flange while firmly rolling the flange. Take care to "crease-in" the Self-Adhered Vent Boot over the seams. Note: Do not cut the side of the pre-molded Self-Adhered Vent Boot. It must be pulled over the vent pipe.
9. Install a bead of FlexSeal™ Caulk Grade Sealant (ensuring primer extends under the FlexSeal) or TPO Cut Edge Sealant around entire perimeter lap of the Self-Adhered Vent Boot for 20 year coverage under the GAF EverGuard Diamond Pledge NDL Roof Guarantees; 15 year guarantee coverage available otherwise.*
10. Install the stainless steel draw band around the top of the Self-Adhered Vent Boot, then add FlexSeal™ Caulk Grade Sealant around the top of the draw band.

Read full application instructions at gaf.com before using or installing this product.

* Additional requirements apply. Contact GAF for more information.

Specifications	
Membrane thickness	.075" (1.9 mm)
For pipe sizes	1" – 6" (25.4 mm – 152.4 mm)
Size	17" (432 mm) wide x 8" (203 mm) tall
Shipping Specifications	
Boots per carton	6
Weight per carton	9 lb. (4.1 kg)
Cartons per pallet	EverGuard® (54)
Shelf Life	12 months from the date of manufacture when stored properly
Product SKUs	
Vent Boot White	77B01920NC



Visit gaf.com

For additional information, contact GAF Design Services at 1-877-423-7663 or designservices@gaf.com

We protect what matters most™

