



Cures like traditional cover tape — without the primer!

Description:

Save time and labor with patent-pending factory-built, easy-to-install Primerless EverGuard™ TPO 6" Cover Tape. Save a step — no primer required! Used for strippingin edge metal, this factory-built accessory reduces risk of leaks and callbacks, and helps create a uniform aesthetic.

The Challenge:

One of the benefits of TPO is its low surface energy and weak molecular attractions. That's what helps it withstand water penetration. But it can also make TPO hard to bond to. That's why we usually recommend a primer — to create a layer with high surface energy — when applying an adhesive. But applying a primer can be timeconsuming and labor-intensive.

The Solution:

GAF uses a proprietary high-tack, highadhesion butyl tape with low-molecularweight "tackifying" resins and adhesion promoters to improve adhesion on our GAF EverGuard™ Primerless TPO Cover Tape. Because these tackifying resins emulate the role of a separately applied primer, it takes a typical 24-hour window to achieve full adhesion, similar to traditional cover tape.*

Specifications	
100¹ (30.5 m)	
6" (152 mm)	
Shipping Specifications	
2	
37.4 lb. (16.96 kg)	
36	
Product SKU	
755P920	

* Both standard and primerless cover tapes require 24 hours to build full adhesion in typical installations.

Product Information:

Self-adherina Primerless EverGuard™ TPO 6" Cover Tape is non-reinforced TPO membrane that is six inches (152 mm) wide and backed with a butyl tape adhesive.

Store material in original unopened packaging at temperatures between 40°F - 110°F (4°C - 43°C). Product shelf life is 24 months from date of manufacture when stored as recommended

Application:

Use soap and water to clean the membrane end lap area or edge metal surface to be covered. Dry the area then wipe it down with a white cloth moistened with EverGuard™ TPO Seam Cleaner or EverGuard™ TPO Low-VOC Seam Cleaner. If using EverGuard™ TPO Aerosol Seam Cleaner, use as directed. Apply Primerless EverGuard™ TPO 6" Cover Tape with a silicone roller. Can be installed on slopes up to 3:12. Install EverGuard™ Primerless TPO Cover Tape at an ambient air temperature of 40°F (4°C) and rising. Heat may be added to the membrane and Cover Tape as needed.



32025 GAF • COMEG536-PDF-1125