



DRILL-TEC™ RHINOBOND®
XHD PLATE



DRILL-TEC™ PURLIN
FASTENER

NOTE:

TPO= YELLOW PLATE
PVC= BLACK PLATE

REINFORCED EVERGUARD®
MEMBRANE (SMOOTH ONLY)

DRILL-TEC™ PURLIN FASTENER &
DRILL-TEC™ RHINOBOND® XHD PLATE.
SEE NOTE 1.

GAF APPROVED COVER BOARD OR
SECOND LAYER OF INSULATION IF
REQUIRED. SEE NOTE 2.

ENERGYGUARD™
ROOF INSULATION
SEE NOTE 2.

STRUCTURAL PURLIN

EXISTING METAL
ROOF PANELS

APPROVED FLUTE FILLER

AIR/VAPOR RETARDER - AS
REQUIRED

NOTE:

1. REFER TO THE DRILL-TEC™ RHINOBOND® PURLIN ATTACHMENT TABLE FOR ADDITIONAL INFORMATION.
2. INSULATION BOARDS INSTALLED IN SINGLE OR MULTIPLE LAYERS MUST HAVE THE JOINTS BETWEEN THE BOARDS STAGGERED IN ALL DIRECTIONS A MINIMUM OF 6" (152 mm) BETWEEN LAYERS.
3. PRELIMINARY FASTENING MAY BE REQUIRED.

GAF

**DRILL-TEC™ RHINOBOND® ASSEMBLY
- PURLIN ATTACHMENT**

DRAWING #
100F

THIS DETAIL APPLIES TO:
RHINOBOND® SYSTEMS

ISSUE / REVISION DATE
8/17/20

SCALE
N.T.S.

LEGEND

HEAT-WELDED