



NOTE:

1. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A COVER BOARD IS REQUIRED ON MECHANICALLY ATTACHED SYSTEMS ONLY.
2. CLEAN METAL AND MEMBRANE WITH EVERGUARD® TPO SEAM CLEANER AND ALLOW TO DRY. ONCE DRY, PRIME METAL AND MEMBRANE WITH EVERGUARD® TPO PRIMER BEFORE INSTALLING EVERGUARD® TPO COVER TAPE.
3. THIS DETAIL IS **NOT** TO BE USED ON SLOPES GREATER THAN 1:12. FOR SLOPES GREATER THAN 1:12, REFER TO EVERGUARD® DETAIL 218 OR 219.
4. DO NOT OVERLAP ENDS OF FLASHING STRIP/COVER TAPE.

GAF

COVER TAPE AT ROOF EDGE DETAIL

DRAWING #

213A

THIS DETAIL APPLIES TO:

ADHERED SYSTEMS
RIVET-BOND SYSTEMS
SELF-ADHERED SYSTEMS
MECHANICALLY ATTACHED SYSTEMS

ISSUE / REVISION DATE

8/24/20

SCALE

N.T.S.

LEGEND