



NOTE:

- 1. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A COVER BOARD IS REQUIRED ON MECHANICALLY ATTACHED SYSTEMS ONLY.
- 2. CLEAN METAL AND MEMBRANE WITH EVERGUARD® TPO SEAM CLEANER AND ALLOW TO DRY. ONCE DRY, PRIME METAL AND MEMBRANE WITH EVERGUARD® TPO PRIMER BEFORE INSTALLING EVERGUARD® TPO COVER TAPE.
- 3. THIS DETAIL IS **NOT** TO BE USED ON SLOPES GREATER THAN 1:12. FOR SLOPES GREATER THAN 1:12, REFER TO EVERGUARD® DETAIL 218 OR 219.
- 4. FLEXSEAL™ CAULK GRADE SEALANT SHOULD BE FEATHERED OUT AND APPLIED TO BOTH INSIDE AND OUTSIDE EDGES. ENSURE PRIMER EXTENDS UNDER FLEXSEAL™ CAULK GRADE SEALANT.



COVER TAPE OVERLAP AT ROOF EDGE DETAIL

DRAWING #  
**215B**

THIS DETAIL APPLIES TO:  
ADHERED SYSTEMS  
RHINOBOND® SYSTEMS  
SELF-ADHERED SYSTEMS  
MECHANICALLY ATTACHED SYSTEMS

ISSUE / REVISION DATE  
**4/5/21**

SCALE  
N.T.S.

LEGEND

- CONTINUOUS BEAD OF FLEXSEAL™ CAULK GRADE SEALANT (SEE NOTE #4)
- EVERGUARD® TPO PRIMER (SEE NOTE #2)