



NOTE:

1. PRIME THE METAL ONLY WITH EVERGUARD® TPO PRIMER. DO NOT SPILL PRIMER ON WELDED SEAM AREA.
2. HEAT WELD THE END JOINT COVER STRIP OF DETAILING MEMBRANE TO THE MEMBRANE AREA USING EITHER A ROBOTIC OR HAND WELDER TO SPEC.
3. REFER TO DETAIL 218 FOR EVERGUARD® COVER TAPE HEATWELD ROOF EDGE INSTALLATION.
4. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A COVER BOARD IS REQUIRED ON MECHANICALLY FASTENED SYSTEMS ONLY.

GAF

COVER TAPE HEATWELD STRIP END JOINT AT ROOF
EDGE DETAIL

DRAWING #

219

THIS DETAIL APPLIES TO:

ADHERED SYSTEMS
RHINOBOND™ SYSTEMS
SELF-ADHERED SYSTEMS
MECHANICALLY ATTACHED SYSTEMS

ISSUE / REVISION DATE

8/24/20

SCALE

N.T.S.

LEGEND

CONTINUOUS BEAD OF FLEXSEAL™
CAULK GRADE SEALANT