

**NOTE:**

1. PRIME THE METAL ONLY WITH EVERGUARD® TPO PRIMER. DO NOT SPILL PRIMER ON WELDED SEAM AREA.
2. HEAT WELD THE MEMBRANE (NON-ADHESIVE SIDE ONLY) TO MEMBRANE AREA USING EITHER A ROBOTIC OR HAND WELDER TO SPEC.
3. REFER TO DETAIL 218 FOR EVERGUARD® COVER TAPE HEAT-WELD ROOF EDGE INSTALLATION.
4. CLEAN METAL AND MEMBRANE WITH EVERGUARD® TPO SEAM CLEANER AND ALLOW TO DRY.

GAF

COVER TAPE HEAT-WELD AT METAL DRIP EDGE CORNER DETAIL

DRAWING #

221

THIS DETAIL APPLIES TO:

ADHERED SYSTEMS
 RIVINBOND® SYSTEMS
 SELF-ADHERED SYSTEMS
 MECHANICALLY ATTACHED SYSTEMS

ISSUE / REVISION DATE

8/24/20

SCALE

N.T.S.

LEGEND