



NOTE:

1. FOR PVC PIPE PENETRATION, CLEAN AND PRIME WITH TPO PRIMER PRIOR TO INSTALLING MAJORSEAL™
2. PENETRATION GAPS GREATER THAN 1/4" REQUIRE BACKER ROD BEFORE APPLICATION OF M-BOND ADHESIVE.
3. FOR CLUSTERS OF PIPES, LEAVE 1/2" MINIMUM BETWEEN PIPES.

GAF

PIPE PENETRATION FLASHING DETAIL

DRAWING #

511

ISSUE / REVISION DATE

2/20/20

SCALE

N.T.S.

LEGEND