

## NOTES

- 1. CLEAN METAL AND MEMBRANE WITH EVERGUARD® TPO SEAM CLEANER AND ALLOW TO DRY. ONCE DRY, PRIME METAL AND MEMBRANE WITH EVERGUARD® TPO PRIMER BEFORE INSTALLING EVERGUARD® TPO COVER TAPE.
- 2. EDGE METAL SHOULD DESIGNED FOR WIND RESISTANCE IN ACCORDANCE WITH THE APPLICABLE EDITION OF ASCE 7. ADDITIONAL REQUIREMENTS APPLY FOR GUARANTEE COVERAGE OF ATTACHMENT TO INSULATED METAL WALL PANELS. CONTACT <a href="mailto:coldstorage.assistance@gaf.com">coldstorage.assistance@gaf.com</a> FOR DETAILS.
- 3. FOR STEEL ROOF DECKS: FILL STEEL DECK FLUTES WITH CLOSED CELL SPRAY FOAM INSULATION PRIOR TO THE INSTALLATION OF ABOVE DECK INSULATION A MINIMUM OF 12" [305 mm] FROM FACE OF WALL.

## Coated Drip Edge with Cover Tape at IMP



We protect what matters most™

**Legend:** Primer

Sealant

Adhesive

.....

Foam

**Product:**EverGuard TPO

**Installation:**Cold Storage
Systems

Maximum Warranty:

**Date:** 2/14/2025

Scale: Not To Scale

**Detail No.** 075423

203D